

A. Installing the MachineRoomRescue Phone

1. Affix the laminated template to the wall where the MachineRoomRescue is to be mounted.
2. Mount the MachineRoomRescue to the wall according to the template. Be sure the RJ11 plug on the wall mates up to the RJ11 jack on the back of the phone.
3. The wire on the side of the MachineRoomRescue needs to be connected to the SmartPhones in the elevator(s).

Important Note: Please see reverse side section D for wiring instructions.

Important Note: Rath Microtech SmartPhone's in each elevator car must be programmed in consolidator mode before you can program the MachineRoomRescue.

For programming the SmartPhone III in consolidator mode, see Section E (reverse side).

For programming the SmartPhone IV in consolidator mode, see Section F (reverse side).

B. Programming the MachineRoomRescue Phone

Important Note: When programming ignore messages from the phone system. Continue and finish programming.

1. Programming Telephone Numbers

- a. Slide program switch to "Prog." position.
- b. Press the "#" key 10 times, you will hear confirmation tones.
- c. Press "3" then "#" then the telephone number assigned to the elevator car(s).
- d. Press "*" then "#."
- e. Hang up the phone.
- f. Slide program switch to operation mode.



2. Switchboard Telephone Line Programming

- a. Slide program switch to "Prog." position.
- b. Press the "#" key 10 times, you will hear confirmation tones.
- c. Press "3" then "#" then press the access code for an outside line (usually 8 or 9).
- d. Press the "#" then "*" then the telephone number assigned to the elevator car(s), (enter the number to be dialed).
- e. Press "*" then "#."
- f. Hang up phone.
- g. Slide program switch to operation mode.

C. Operating the MachineRoomRescue Phone with SmartPhone III and IV

Operation with the SmartPhone III (5 Phones)

Lift the handset of the MachineRoomRescue Phone and it will automatically dial the SmartPhone III, all phones will answer active.

a. To Select Individual Phone

- Press *1 (Phone #1)
- Press *2 (Phone #2)
- Press *3 (Phone #3)
- Press *4 (Phone #4)
- Press *5 (Phone #5)

b. To select All phones

Press "*" then "0" - establishes 2 way conversation with all units.

c. To select All Phones (page mode)

Press "*" then "9" - establishes listening mode only in elevator.

Operation with the SmartPhone IV (10 Phones)

Lift the handset of the MachineRoomRescue Phone and it will automatically dial the SmartPhone IV, all phones will answer active.

a. To Select Individual Phone

- Press *1 (Phone #1) Press #1 (Phone #6)
- Press *2 (Phone #2) Press #2 (Phone #7)
- Press *3 (Phone #3) Press #3 (Phone #8)
- Press *4 (Phone #4) Press #4 (Phone #9)
- Press *5 (Phone #5) Press #5 (Phone #10)

b. To select All phones

Press "*" then "0" - establishes 2 way conversation with all units.

c. To select All Phones (page mode)

Press "*" then "9" - establishes listening mode only in elevator.